





AKERS


Craftsman Three Door Bookcase

Walt Akers - 1999


Directional Views of Assembled Cabinet



Front




Side




Top

Exploded Assembly of Cabinet Back




- A) Left Rear Leg
- B) Right Rear Leg
- C) Top Rear Stretcher
- D) Bottom Rear Stretcher
- E) Side Rear Panel
- F) Center Rear Panel
- G) Center Rear Stile

Exploded Assembly of Cabinet Door




- A) Left Door Rail
- B) Right Door Rail
- C) Top Door Stile
- D) Center Door Stile
- E) Bottom Door Stile
- F) Bottom Door Pane
- G) Top Pane Group

Exploded Assembly of Cabinet Front




- A) Top Front Stretcher
- B) Bottom Front Stretcher
- C) Left Front Leg
- D) Right Front Leg
- E) Center Front Stile
- F) Left Front End-Stile
- G) Right Front End-Stile

Exploded Assembly of Cabinet Side




- A) Top Side Stretcher
- B) Bottom Side Stretcher
- C) Right Rear Leg
- D) Right Front Leg
- E) Center Side Stile
- F) Side Panel
- G) Side Panel

Exploded Assembly of Cabinet Center Panel



- A) Rear Center Stile
- B) Front Center Stile
- C) Center Panel


Exploded Assembly of Cabinet Bottom




- A) Bottom Rear Stretcher
- B) Bottom Front Stretcher
- C) Bottom Left Side Stretcher
- D) Bottom Right Side Stretcher
- E) Right Rear Leg
- F) Left Rear Leg
- G) Right Front Leg
- H) Left Front Leg
- I) Bottom Panel

Leg


Top View



Side View




Front View




Front Center Stile


Top View



Side View




Front View




Front End Stile


Top View



Side View




Front View




Rear Center Stile


Top View



Side View




Front View




Side Panel

Side View




Front View




Bottom Side Stretcher


Top View



Side View




Front View




Top Side Stretcher


Top View



Side View




Front View




Side Center Stile


Top View



Side View




Front View




Bottom Front Stretcher


Top View



Side View




Front View




Bottom Rear Stretcher


Top View



Side View




Front View




Top Front Stretcher


Top View



Side View




Front View




Top Rear Stretcher


Top View




Side View




Front View




Side Shelf





Center Shelf




Cabinet Bottom






Center Panel




Top Plank


Front View



Side View




Front View




Door Rail


Top View



Side View




Front View




Top Door Stile


Top View



Side View




Front View




Center Door Stile


Top View



Side View




Front View




Bottom Door Stile

Top View



Side View



Front View

