

NOTICE

The purchaser agrees when purchasing this product to accept the right to build or construct the object or project set out in the Plan (the "Project") for his/her/its personal use only and not for any other purpose. Any reproduction of the Plan in whole or in part by any means whatsoever is strictly prohibited. Blueprints for the Handymen Project are provided for informational purposes only. The use of this plan, the Project or for any other purpose, without the express written consent of the publisher, may result in loss or damage resulting therefrom.

PO Box 188
340-3545 32nd Ave NE
CALGARY, ALBERTA, CANADA
T1Y 6M0

NOTE: Read all directions before beginning

- Corpenr's glue should be used to reinforce all joints
- Set all nails and countersink screws - use wood filler as necessary to spot nails and screws before finishing wood
- Dimensions shown in brackets denote millimetres
- Wipe off excess glue with a wet cloth before it has time to set

Directions:


Procedure 1) - See Figure 1

Begin your project by laying out all materials as illustrated in Figure 1 (Material Layout). Using a pencil, measuring tape and straightedge, (along with a protractor, compass or miter gauge if required) draw out all the parts exactly as shown using the dimensions and shapes illustrated in Figure 2 (Cutting Diagram). Be sure to include the part number designation for each piece as well. The dados in pieces B may be made using a dado blade or using multiple cross cuts, on your table saw. If you don't have a jig saw or band saw, the curved areas can be cut with a coping saw or merely cut straight with a table or hand saw, and sanded to final shape.


The angles on pieces D & H are important, as any change in these will affect the fit of other pieces as well as the angle of the seat back. The large 24" radius arc that forms the curve of the seat and back in pieces A, G, & L may be drawn using a pencil with a 24" string tied to it. Ensure the focal point of the arc is located as precisely as possible using the dimensions as illustrated in the Cutting Diagram.

Due to the complexity and number of various pieces, and as this is an outdoor item, we recommend finishing with stain or oil prior to assembling the project.


TETE-A-TETE (Straight) COMPLETED PROJECT



CUT PIECES:
A, B, C, G, L,
FROM 3 LENGTHS
27x3x8"



MATERIALS LAYOUT
FIGURE 1



CUTTING DIAGRAM
FIGURE 2

MATERIALS LIST

- Three 27x3x8" (Cedar or Redwood)
- One 27x2x4" (Cedar or Redwood)
- Seven 27x2x8" (Cedar or Redwood)
- Three 27x4x8" (Cedar or Redwood)
- Three 17x4x5" (Cedar or Redwood)
- One 17x3x10" (Cedar or Redwood)

MATERIALS LIST

- Approx. 100 1-1/2" #10 Flathead Screws
- Approx. 50 2-1/2" #10 Flathead Screws
- Corpenr's Glue
- Sandpaper
- Oil or Stain

TOOLS

- Table Saw and Jigsaw
- Pencil, Tape, and Square
- Power Drill and Protractor
- 5/64" 3/32" 7/64" drill bits
- Hammer and Screwdrivers
- Paint Brush and Putty Knife
- Power Sander (optional)

Blueprints for the Handyman Presents
TETE-A-TETE (Straight) - Project #217

© 1990 Blueprints for the Handyman