

NOTICE

The purchaser agrees when purchasing this plan (the "Plan"): 1) that the purchaser has acquired the right to build and construct the object of the project set out in the Plan (the "Project") for his/her/its personal use only and not for any commercial use; 2) that reproduction of the Plan in whole or in part by any means whatsoever is strictly prohibited; 3) Blueprints For The Handyperson shall not be liable for any willful misuse or negligent use of this plan, the Project, or any tools used to construct the Project, or for any loss or damage resulting therefrom. *


NOTES: Read all dimensions before beginning!

Components glue should be used to join. Dimensions shown in brackets denote millimeters. Set all nails and countersink all screws.

Directions


- 1) Lay out your material as outlined in the suggested material layout (Fig 1). Draw out all parts exactly as illustrated in cutting diagram (Fig 2), including the letter designations, in pencil. Ensure to leave a small space between cut lines to allow for the width of the saw. Before cutting, double check all measurements to ensure they are correct. Always cut on the waste side of the line. You can cut the rabbit joint in piece A (Fig 3) with either a table saw with the blade set to cut deep, scry pieces of wood. The finger holes in K and H can be cut with either a jigsaw or coping saw and sanded smooth.
- 2) Layout the pieces A and drill 1/4" holes (assuming your shelf support brackets are 1/4" dia.) to a depth of 3/8" using a 1/4" bit and depth gauge (illustration 1), as shown (Fig 4). Glue and nail pieces L and M to the right piece A, and one of the pieces G with 3/4" finishing nails. Use a piece J to get the proper spacing between the pieces. Note that pieces M and L are flush with the rear of pieces G and the inset of the rabbit on A, and piece M is flush with the top of G. Glue and nail pieces S to pieces A, 4 3/4" from the bottom of pieces A, with 3/4" finishing nails.

OTHER





Make a depth gauge for your drill — By drilling through a 3/4" x 3/4" piece of wood (shown) to a pre-measured depth of drill and place over drill bit.

DRILL DEPTH GAUGE ILLUSTRATION 1



RABBIT DETAIL FIGURE 3



MATERIALS LAYOUT FIGURE 1







FIGURE 4

CUTTING DIAGRAM FIGURE 2

MATERIALS LIST

- Approx. 1 lb. 1 1/2" finishing nails
- Approx. 1/2 lb. 1 1/4" finishing nails
- One sheet 4x8 3/4" plywood, good both sides
- One sheet 4x8 1 1/4" plywood, good both sides
- One 3 1/8 (3/4x35 1/2")

MATERIALS LIST

- Wood putty or filler
- Sandpaper & Carpenters glue
- Stain and varnish, or oil
- Two 3" hinges & hardware (5/8")
- Three square pulis & hardware
- Nine 3" edgetype (optional)

TOOLS

- Table Saw and Jigsaw
- Pencil and Measuring Tape
- Power or Hand Drill
- Handmade and Nail Saw
- Plane and Wood Chisels